



# Abri-Soft

## Product guide



### Step 1:

Find the right underpad based on your intended use:

		What is the needed absorption level?					
		▲▲ ○○○	▲▲▲ ○○○	▲▲▲ ○○○	▲▲▲ ○○○	▲▲▲ ○○○	▲▲▲ ○○○
What is the intended use?	Extra protection for incontinence	<u>Ultra Light</u>	<u>Light</u>		<u>superdry</u> *		
	Bed bathing and hygiene			<u>Basic</u>		<u>classic</u>	
	Wound care	<u>Ultra Light</u>	<u>Light</u>	<u>Basic</u>	<u>superdry</u> *	<u>classic</u>	<u>Excellent</u>
	Surgery			<u>Basic</u>	<u>superdry</u> *		
	Birth				<u>superdry</u> *	<u>classic</u>	<u>Excellent</u>
	Examination and clinic	<u>Ultra Light</u>	<u>Light</u>	<u>Basic</u>		<u>classic</u>	
	Blood tests	<u>Ultra Light</u>					



### Step 2:

Choose your product and size:

	<u>Ultra Light</u>	<u>Light</u>	<u>Basic</u>	<u>superdry</u> *	<u>classic</u>	<u>Excellent</u>
60 x 90 cm	<b>1000017869</b> Absorption 800ml	<b>254118</b> Absorption 1250ml	<b>4118</b> Absorption 1700ml	<b>254123</b> Absorption 1500ml *	<b>4123</b> Absorption 2200ml	<b>4109</b> Absorption 2900ml
60 x 75 cm					<b>4122</b> Absorption 1700ml	
60 x 60 cm	<b>1000017868</b> Absorption 700ml	<b>254117</b> Absorption 850ml	<b>4117</b> Absorption 1000ml	<b>254119</b> Absorption 1000ml *	<b>4119</b> Absorption 1300ml	
40 x 60 cm	<b>1000017876</b> Absorption 650ml	<b>254116</b> Absorption 700ml	<b>4116</b> Absorption 800ml	<b>254115</b> Absorption 800ml *	<b>4115</b> Absorption 900ml	

\*Contains SAP (Super-absorbent Polymer). SAP turns liquid into gel and keeps the surface of the underpad dry longer. Products containing SAP are recommended for any situation where the surface needs to be kept dry for a longer period of time.

Contact your local sales rep for further guidance about finding the right environmentally friendly underpad for your needs:

[www.abena.com/products/bed-protection](http://www.abena.com/products/bed-protection)